



CALL SETUP FOR 'SIP TO FIXED-WIRE PSTN' INTERWORKING



CALL SETUP FOR 'SIP TO MOBILE' INTERWORKING



CALL SETUP FOR 'PSTN TO SIP' INTERWORKING






FIG. 4






FIG. 5

4/4





CALL SETUP FOR 'PSTN TO SIP' INTERWORKING WITH UMM